## Main Menu

Home

**Purchase Games** 

History

Wiki

#### Games

Adventures of Tron

All-Star Hockey

Choplifter

**Deep Pockets** 

Donkey Kong Arcade

Flintstones

Keyboard Fun Illusions

King of the Mountain

Minehunter

Ms Night Stalker

Ms Pac Man

Rocky & Bullwinkle SameGame and

Robots Scarfinger

Space C\*nt

Spina the Bee

Stonix

Super Chef BurgerTime

Super NFL Football

Super Pro Baseball

Super Pro Tennis

Yogi's Frustration

#### Hardware

Classic Game Controller

Reproduction

Boxes

Ultimate Console
Ultimate PC

Interface

Adam keyboard

### **Emulation**

jzIntv

Nostalgia Download ROMs

\_\_\_\_

## Misc Intellivision Lines

# Colecovision Adam Keyboard PC Interface for the PC/MAC/Raspberry



# About and Using the Interface

Rekindle the love you had for your Adam keyboard without the need for the printer or console by using the Adam Keyboard PC Interface!

In 1983, I purchased a Coleco Adam Computer and fell in love with keyboard. After all these years, I missed my Adam keyboard and wanted a way to use it again without the printer and console. In 2015, the necessary components to have this interface made just came together allowing me to use an Adam keyboard again!

The Adam Keyboard Interface is simply a device that allows you to connect the keyboard to a PC, Mac, or Raspberry computer. The computer will see the keyboard as an HID (human interface device). There are no software drivers required; plug and play!

The special keyboard keys such as WILD CARD and UNDO are mapped to common computer keys (documented below). This configuration allows you to use the keyboard as a normal keyboard and in emulation. The **CoolCV** (Colecovision/Adam) emulator has Adam support and will give you the feeling like you are back in 1983!

CLICK HERE for a sample of the CoolCV mapping configuration file for the Adam Keyboard interface. The emulator will clean out the comments.

The function keys are mapped as:

ADAM KEYS	PC/MAC KEYS
Escape	Escape
Wild Card *	Left Alt/Option
Black 1-6	F1-F6
Shift Black 1-6	F7-F12
Undo **	Pause
Move/Copy	Page Up
Store/Get	Page Down
Clear	End
Insert **	Insert
Print **	Print Screen
Delete	Delete/Del
Home	Home
Tab	Tab
Control	Left Control/Command
Shift	Left Shift
Lock	Caps Lock
Return	Enter/Return
Backspace	Backspace/Delete

\* NOTE: When using the keyboard on the PC or Mac, be aware that the WILD CARD key does not work in combination with any other keys. CONTROL and SHIFT do.

\*\* NOTE: There are no Mac equivalent keys for the UNDO, INSERT, and PRINT keys.

If you have a Mac, you may want to remap the COMMAND key. THIS SITE has instructions on how to do this.





2 of 2