

Orphanware
P.O. Box 324
Canal Fulton, OH 44614
216-882-4720

RMTST.COM is a CP/M program designed to test any size ADAM memory expansion by any manufacturer. It does a bit by bit check of the integrity of each memory chip on the board.

To use it, boot CP/M and then put in the disk containing RMTST.COM and enter the following:

A>RMTST<CR>

RMTST will first test for the size of the expansion ram up to 1 megabyte and then cycle thru several different bit patterns in each block of memory. Errors will show the expected bit pattern and the received bit pattern. A good test will say DONE.

To display results to the LST device (printer): A>RMTST /P<CR>

To run the results to the printer, you need not press ^P as the program will automatically enable the printer port.

This program must be run under CP/M and you must remember that when the program is run, you destroy all the contents of the RAM DRIVE.

This program is warranted for a period of 90 days to be free from defects in materials or workmanship. If you should have a problem, return the program disk and proof of purchase to:

Orphanware
P.O. Box 324
Canal Fulton, OH 44614