

COLECOVISION™

PROGRAMMER'S MANUAL

restored by

Richard F. Drushel

12 February 1992

My thanks to Barry Wilson, A.N.N., for the generous (and prolonged) use of his original copy of this manual.

TABLE OF CONTENTS

	Page
III. GRAPHICS GENERATION SOFTWARE.....	3-1
3.1. Chip Driver Level.....	3-1
3.1.1 READ_VRAM.....	3-4
3.1.2 WRITE_VRAM.....	3-6
3.1.3 READ_REGISTER.....	3-8
3.1.4 WRITE_REGISTER.....	3-11
3.1.5 FILL_VRAM.....	3-13
3.1.6 MODE_1.....	3-15
3.2 Table Level.....	3-17
3.2.1 Table Managers.....	3-21
3.2.1.1 INIT_TABLE.....	3-22
3.2.1.2 GET_VRAM.....	3-25
3.2.1.3 PUT_VRAM.....	3-29
3.2.2 Table-Oriented Graphics Routines.....	3-32
3.2.2.1 REFLECT_VERTICAL.....	3-35
3.2.2.2 REFLECT_HORIZONTAL.....	3-40
3.2.2.3 ROTATE_90.....	3-45
3.2.2.4 ENLARGE.....	3-51

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

TABLE OF CONTENTS

	Page
3.2.3 Sprite Reordering Software.....	3-57
3.2.3.1 INIT_SPR_ORDER.....	3-61
3.2.3.2 WR_SPR_NM_TBL.....	3-63
3-3 Object Level.....	3-65
3.3.1 Object Types.....	3-65
3.3.1.1 Semi-Mobile.....	3-66
3.3.1.2 Mobile.....	3-66
3.3.2.3 Sprite.....	3-66
3.3.1.4 Complex.....	3-67
3.3.2 Object Data Structure.....	3-67
3.3.2.1 Graphics Data Area.....	3-67
3.3.2.2 Status Area.....	3-68
3.3.2.3 OLD_SCREEN.....	3-68
3.3.3 ACTIVATE.....	3-69
3.3.4 PUTOBJ.....	3-71
IV. INTERRUPT HANDLING AND WRITE DEFERRAL.....	4-1
4.1 INIT_WRITER.....	4-3
4.2 WRITER.....	4-5

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

TABLE OF CONTENTS

	Page
V. TIMING SOFTWARE.....	5-1
5.1 Non-Repeating Timer.....	5-2
5.2 Repeating Timer.....	5-2
5.3 TIMER_TABLE.....	5-2
5.3.1 Mode_Byte.....	5-3
5.3.2 Value_Word.....	5-3
5.3.3 TIMER_DATA_BLOCK.....	5-4
5.4 INIT_TIMER.....	5-5
5.5 TIME-MGR.....	5-7
5.6 REQUEST_SIGNAL.....	5-9
5.7 TEST_SIGNAL.....	5-12
5.8 FREE_SIGNAL.....	5-14
VI. CONTROLLER SOFTWARE.....	6-1
6.1 Controller Data Area.....	6-2
6.2 POLLER.....	6-6
6.3 DECODER.....	6-8
6.4 CONT_SCAN.....	6-10
6.5 UPDATE_SPINNER.....	6-11

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

TABLE OF CONTENTS

	Page
VII. SOUND GENERATION SOFTWARE.....	7-1
7.1 LST_OF_SND_ADDRS and PTR_TO_LST_OF_SND_ADDRS...	7-2
7.2 SOUND_INIT.....	7-2
7.3 PLAY_IT.....	7-4
7.4 SOUND_MAN.....	7-6
7.5 PLAY_SONGS.....	7-8
7.6 Application.....	7-9
VIII. BOOT_UP SOFTWARE.....	8-1
8.1 Power-Up Procedure.....	8-1
8.2 Title Screen.....	8-3
8.3 Cartridge Present Identifier.....	8-3
IX. MISCELLANEOUS UTILITIES.....	9-1
9.1 ADD816.....	9-1
9.2 DECLSN.....	9-3
9.3 DECMSN.....	9-4
9.4 MSNTOLSN.....	9-5
9.5 RAND_GEN.....	9-6
9.6 LOAD_ASCII.....	9-7

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26

TABLE OF CONTENTS

	Page
I. DEFINED REFERENCE LOCATIONS.....	10-1
10.1 OS ROM.....	10-1
10.1.1 Europe/America Byte.....	10-3
10.1.2 Restart Vectors.....	10-5
10.2.3 Graphics Tables.....	10-6
10.2 CART_ROM.....	10-6
10.3 CRAM Areas.....	10-8

APPENDICES

- A. Bibliography
- B. Graphics Documentation
- C. Sound Documentation
- D. ColecoVision Bulletins
- E. Jump Table
- F. OS_SYMBOLS
- G. Timing Software Data Structure
- H. OS Subroutine Library
- I. ASCII Generator Set

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26